
ZABUDOWA KABINY C.F.BERG



SCANIA



R P SERIES 4 R P SERIES 5 R P SERIES 6



P SERIES 4







S0488021 S0488034 1370108 1386960



S0488008 1386958



S0475014 1397571



S0488007 1386957



S0488019 S0488020 1386959 1370107






S0482004 1387155



S0482002 1446588



S0488002 1324600



S0475007 1366384



S0488001 1324599



S0482001 1446587



S048 2003 1385 410



S0488063 1376832









S0482021 S0482015 S0482018





S0466024

\$0452006

1354594

1515194







S0466002 1351203







S0466001

1390076

S0466002 1351203

\$0452005 1354593















S0462001 1488409 LH



S0462002 1488410 RH



S0401004 581025



S0401011 1390705



S0401010 1390706





\$0481007 1366847 LH



S0481008 1366848 RH



S0472010 1442292 LH



S0472011 1442293 RH



S0401012 1511775



\$0402001 1450903



S0402002 1549740



S0472008 1406223 LH



\$0472009 1406224 LH



S0452035 1378187




S0401015 1440499



S0401016 1736908



S0401014 1753473









S0488047 S0488046

1523508 1523509

S0488049

S0482026

S0482014

1446356

S0488046

1523509

50488047

1523 508

1747981

1413898

S0488043

1438558

S048 6004

P SERIES 5









S0452002 1436867



\$0452027

1721892

S0454023 2026620 \$0452036

S0452003 1436868


S0452029 1792686

S0401007

S0454018 1785531



S040 1005 1785 530



S0469001

8416311

\$0491002

1894206

\$0454020

1746067

S0499001

1518142

\$0499002





S0493015 1862799

S0493006 1922234 \$0493016

1380957

\$0493014

\$0493005

1392755

1862892

S0493012 1862802

S0493003 1500199

1548262

S0493013 1862800

50493004

S0481005 1443864 S0481003 1732783 S0481004 1723519 S0481001 1723518 S0481006 1346377







S0466028 1805342











1456917

S0472016 1459363

S0472012 1769912

R SERIES 6

